




Cinta alimentación de piezas







Cable ethernet de salida de la camara Cognex In-singt 5100


Cable ethernet de salida de la camara Cognex In-singt 5100


Cable ethernet de salida de la camara Cognex In-singt 5100






















[illegible]





- EXT_START /
- LOW_AIR /
- MASTER_JOB /
- ALARM_RESET /
- /
- SELEC_PLAY_MOD /
- SELEC_TEACH_MOD /
-
- INTER_1 /
- INTER_2 /
- WORK_PROHIBITED /
- RUNING /
- SERVOS_ON /
- TOP_MASTER /
- ALARM_ERROR /
- BATERY_ALARM /
- REMOTE_MODE /
- PLAY_MODE / 37.3
- TEACH_MODE / 37.3
- IN_CUBE1 / 37.3
- IN_CUBE2 / 37.3
- WORK_HOME_POS /
- START_OK /

